



Assembly Instruction

Studio Star Roller Shutter Type SI -Motor Drive-



This assembly instruction contains important information on assembling roller shutters as well as important safety instructions.

The assembly operation may only be carried out by specialized staff of Schanz Rollladensysteme GmbH or technicians especially authorized by Schanz Rollladensysteme GmbH.

Schanz Rollladensysteme GmbH

Forchenbusch 9

D- 72226 Simmersfeld

Tel.: +49 (0)7484/9291-0

Fax: +49 (0)7484/9291-36

E-Mail: info@schanz.de

Internet: www.schanz.com



Commission - Nr.	Date Installation and Instruction	Signature

Content

General Safety Information	2
Transport / Packaging / Unpacking.....	2
Assembling / Installation/ Working on the facade.....	2
Assembly Drawing	3
Cord Guidance.....	4
Modification: "Without lateral height" – Assembly Drawing and Cord Guidance	5
Description of the basic procedure	6
Copyright/ References to this documentation	12

General Safety Information

This assembly instruction contains information for the correct installation of Schanz roller shutters. Due to the different types deviations may occur from this assembly instruction. However, this does not affect the security information.

Below described assembly steps may only be carried out by specialized staff of Schanz Rollladensysteme GmbH or technicians especially authorized by Schanz Rollladensysteme GmbH.

Adhere to the applicable regulations of the insurance association and take the necessary precautions for all work and consider the safety instructions in this document. Depending on accessibility, scaffoldings, ladders, fall protection devices, lifting devices and Personal Protective Equipment (e.g. safety helmet, safety boots etc.) are to be used.





Transport / Packaging / Unpacking

Depending on the route of transport and the expected conditions the roller shutter will be packed and the roller shutter jacket will be fixed in the roller shutter box. Depending on the type and size of the roller shutters they might be so heavy that a suitable load-carrying equipment and lifting tool has to be utilized.

Only use sufficiently dimensioned, safe and correctly fixated load-carrying equipment and lifting tools and avoid damages and injuries.

Check immediately if the product has been delivered without damage. Immediately complain about damaged roller shutters.

Removing the transportation protection:

Unscrew and open the cover of the roller shutter box	
Remove the foam sheets Caution: The roller shutter jacket could unwind itself due to the initial tension within the drive system!	
Remove entry mouth	
Remove the 4 slats which are connected to the jacket Put on the cover and screw it back	

Assembling / Installation/ Working on the facade

Each roller shutter is individually manufactured according to your window shape and size and must only be installed by Schanz Rollladensysteme GmbH or technicians especially authorized.



The installation of the roller shutter has to be conducted following the information given in the assembly and safety instructions.

The installation of the roller shutters should only be conducted on ready-made rainproof facades!


The plastering of the roller shutter could lead to severe damages due to damp and furthermore make essential reparation difficult or even impossible.




The water drain holes on the bottom of the roller shutter box have to be clear at all times so that ingressed water can drain off!
Under no circumstances may the shutter box be buried in the wall or stucco.

The roller shutter has to be fixed sufficiently and safe attuned to the ground!


Assembly Drawing






Cord Guidance








Modification: "Without lateral height" – Assembly Drawing and Cord Guidance










Description of the basic procedure

Step No.	Operation	Note	Check
	Check delivery for completeness		<ul style="list-style-type: none"> - Delivery is complete - Compare the goods with delivery note
00	Screw substructure to the window frame with appropriate fixing material	Optional	
10	Check the position of the cable outlet on the shutter box. Mark the hole for the cable routing on the window frame (optional substructure) <ul style="list-style-type: none"> - Basic Position: x-axis = 10 mm; y-axis = 30 mm 		<ul style="list-style-type: none"> - Correct Position of cable routing
20	Drill cable routing through window frame (optional: substructure) with Ø 10 mm		
30	Lead cable through and align shutter box <ul style="list-style-type: none"> - Pass cable through and put the shutter box on the windowsill - Seal the hole with silicone - Check if the shutter box mounts horizontally on the windowsill using a spirit level. If necessary underlay the shutter box. - The drainage holes on the bottom of the roller shutter must be free so that ingressed water can drain off. 		<ul style="list-style-type: none"> - Overlay is necessary





Step No.	Operation	Note	Check
40	<p>Attach guide rail on the motor side</p> <ul style="list-style-type: none"> - Put the guide rail on the box - Check the correct position using a spirit level - Screw the guide rail with appropriate fixing material and according to the number of fixing holes on the guide rail to the window frame (optional: Subconstruction) 		
50	<p>Pulling the cord through</p> <ul style="list-style-type: none"> - Pull the cord through the guide rail and over the cord roll. 		
60	<p>Attach guide rail on the cord side</p> <ul style="list-style-type: none"> - Put the guide rail on the bo - Check the right position using a spirit level - Screw the guide rails with appropriate fixing material and according to the number of fixing holes on the guide rail to the window frame (optional: Subconstruction) 		<ul style="list-style-type: none"> - Do not damage the cord

Step No.	Operation	Note	Check
70	<p>Attach Guide base</p> <ul style="list-style-type: none"> - Push the guide base between roller shutter jacket and window frame (substructure) onto the bottom of the box and align it. - Screw the guide base with appropriate fixing material and according to the number of fixing holes on the guide rail to the window frame (optional: Subconstruction) 		
80	<p>Blende mit Schnurrolle montieren</p> <ul style="list-style-type: none"> - Lead the cord over the cord roll and put on the bezel. - If necessary adjust the position of the cord roll (unscrew the grub screw beforehand and then tighten it again after correction) - Predrill a hole for the countersunk screw and lower it, then screw the bezel through the cord roll using appropriate screws, to the window frame (optional substructure). 		<ul style="list-style-type: none"> - Position of the cord is perpendicular - Do not damage the cord - Mind the cord roll below the bezel

Step No.	Operation	Note	Check
90	<p>Attach bezels to the guide rails</p> <ul style="list-style-type: none"> - Attach the bezel (with cord roll) and screw it with short tapping screws to the guide rail <ul style="list-style-type: none"> - Attach the bezel (without cord roll) and screw it with short tapping screws to the guide rail 	 	<ul style="list-style-type: none"> - Do not damage the cord
100	<p>Blenden miteinander verschrauben</p> <ul style="list-style-type: none"> - Blenden ausrichten und mit Bohrschraube verschrauben 		<ul style="list-style-type: none"> - Schnur nicht beschädigen - Schnurrolle unter der Blende beachten

Step No.	Operation	Note	Check
110	<p>Attach the cord</p> <ul style="list-style-type: none"> - Pull the cord end in the end rail and through the end rail inset and knot it together - Pull the cord through completely until it is tight - The distance of the knot to the end rail hole should be 150 mm max. <p>Note: In case the end rail is too long the roller shutter jacket can be pulled out of the box and thereby the knot can be set to the required position</p> <ul style="list-style-type: none"> - Overhanging cord should <u>not</u> be cut immediately after the knot – leave it longer for approximately 100mm - Melt the end of the cord with a cigarette lighter <p>Put the end rail inset into the end rail and stow the remaining cord in the end rail.</p>	 	<ul style="list-style-type: none"> - Overhanging cord is completely within the end rail
120	<p>Attach Roller shutter box</p> <ul style="list-style-type: none"> - Unscrew the screws of the box lid and open the roller shutter box <ul style="list-style-type: none"> - Screw the roller shutter box on the left and the right side through the side part and back panel with appropriate fixing material to the window frame (optional: substructure) <p>To prevent the box from twisting due to the forces acting, it must be fastened.</p>	 	

Step No.	Operation	Note	Check
	<p>Note: It is recommended to perform this step after setting the roller shutter</p>		
130	<p>Install the stabilizer</p> <ul style="list-style-type: none"> - Put the stabilizer foot into the stabilizer - Push the stabilizer with the intended slit on the bezels - Pre-drill a hole for the countersunk screw, lower it and then screw together the stabilizer with the bezels using an appropriate screw. - Place the hole cap - Align the stabilizer and screw it with the provided drilling screws to the box - Screw together the stabilizer with the stabilizer foot. 		<ul style="list-style-type: none"> - Mind the correct position - The end rail of the roller shutter jacket may not be clamped

Step No.	Operation	Note	Check
140	Completion of the installation: Place the hole caps according to the amount of anchor points on the guide rail		Final inspection: <ul style="list-style-type: none"> - The roller shutter is accurately tight and hole caps are available - Water drain holes are clear - Roller shutter is working - Instruction took place - Documentation handed over
	Setting the roller shutter according to the Operating Instructions “Electronic Motor”, “Wireless-Electronic Motor” or “Mechanical Motor” <u>Default delivery status:</u> (Drive with electric motor) <ul style="list-style-type: none"> - The system is preloaded - The motor is in learning mode Attention: Please note the information labels on the roller shutter box!	 <div style="border: 1px solid black; padding: 5px;"> <p>!Attention!</p> <p>The roller shutter slat could unwind itself due to the initial tension within the drive system!</p> <p>Ensure correct direction of rotation of the cord pulley, because the cord can wind up even with incorrect direction of rotation to the cord pulley!</p> <p>The roller shutter should be within 5 seconds to the top!</p> </div> 	
	Connect the roller shutter according to the instruction „Connecting Diagram”		

Copyright/ References to this documentation

The copyright (copyright ©) for the present documentation is being kept by Schanz Rollladensysteme GmbH as well as partially by the suppliers of the sub vendor documentation. The containing information is solely designed for the operating companies of our roller shutters. It may not be changed, extended, duplicated, saved on data linked institutions and spread without our written agreement nor should it be used for other purposes. The containing information in this document makes no claim to be complete. We have done everything to reflect the content concerning our products to be correctly and up to date. However a warranty for the correctness of the documentation cannot be given. Especially photographs and other images can contain components which do not belong to the standard scope of delivery (options), or which have been changed in the meantime. Changes in connection with a further development as well as the „state of technology“ are subject to alteration.
 Copyright © Schanz Rollladensysteme GmbH, 2023